



**Bearicuda, Inc**

3 West Street, Suite 3E, Litchfield, CT 06759-0056

Tel: 1-877-232-7428 www.bearicuda.com

## 2x4 Garbage Bin Assembly Instructions



### 2x4 Garbage Bin Kit Shipping Contents

<b>Pkg. # 1</b>	<b>Part</b>		<b>Pkg.# 2</b>	<b>Part</b>
<b>Floor</b>	<b>A</b>		<b>Gable</b>	<b>G</b>
<b>Rear</b>	<b>B</b>		<b>Lid</b>	<b>J</b>
<b>Rear</b>	<b>C</b>		<b>Door</b>	<b>H</b>
<b>Plans</b>	<b>E</b>		<b>Door</b>	<b>I</b>
<b>Kit Screws</b>	<b>K</b>			
<b>Door Header</b>	<b>D</b>			
<b>Gable</b>	<b>F</b>			

## Step One

Sit the base on a flat level surface.  
Attach the floor panel A to each Gable  
Panel F and G. Screws up from the bottom.  
Install the gable ends flush with front allowing  
a even surface for the doors to close against.



## Step Two

Fasten the two rear  
panels to the base  
Labeled B and C  
screw into the floor  
panel A and each  
gable end F and G



## Step Three

Install the Door Header Panel D  
Using a straight edge keep the  
Header in a straight line with the  
gable end. The header should sit up  
tight to the lid allowing the lid to sit  
flush on all sides.



The Door stop faces down



## Step Four

Install the flip top lid, Panel J The rear of the Panel the narrow pivot is installed level and flat. Keep an even reveal on all sides. When the lid is closed it should lay flat without any spaces.



## Step Five

Install the door panels H and I As you look at the bin Door I is on the left and door H is on the right. Door H has the closure board.



# Manchester 2x4 Bin Assembly

## Screw Positioning

The two ends are attached to the floor using seven to eight 1-5/8" Zinc Screws. These will screw into the small backing board on the floor panel.



Rear attached in two pieces. Each piece is attached to the two ends and the floor using three 1-5/8" screws on the bottom and seven to eight running up the sides.



Front is attached using two 1-5/8" Zinc screws each side.



Doors are hung using the black hinge screws.





The lid is screwed into the back wall using seven to eight 1-5/8" zinc screws along the top of the back wall.